

Coffret de calage pour PSA 1.2 puretech 12V turbo



DESCRIPTIF

Deskriptif :

Modèles :

Citroën : Berlingo II, Berlingo III, C3 IV, C3 Aicross, C3 Picasso, C4 Cactus, C4 III, C4 Picasso, C4 Space Tourer, C5 Aircross.

Codes moteurs :

1PP, 5F01, 5FS, 5FS, 5F01, 5G06, 5GF, 5GF, 5G06, BNZ, AH01, B12XE, B12XEL, B12XHL, B12XHT, BH02, BHY, BHY, BH02, BNZ, D12XE, D12XE, F12XE, D12XEL, D12XHL, D12XHL, F12XHL, D12XHT, D12XHT, F12XHT, DV5RC, DV5RCD, DV5RCF, DV5RD, DV6FD, DW10BTED4, DW10FC, DW10FC, DW10FDCU, DW10FDCU, EB0, EB2, EB2, EB2D, EB2F, EB2, EB2F, EB2ADT, EB2ADT, EB2ADTD, EB2ADTD, EB2ADTDB, EB2ADTS, EB2ADTX, EB2D, EB2D, EB2FD, EB2DT, EB2DTM, EB2DTS, EB2DTS, EB2DTS, EB2F, EB2FA, EB2FAD, EB2FB, EB2FD, EHZ, EHZ, AH01, EP6C, EP6FADTXD, F12XE, F12XHL, F12XHT, HM01, HM02, HM03, HM05, HMM, HMM, HM05, HMM, HMM, HM05, HMP, HMP, HM01, HMR, HMR, HM05, HMT, HMT, HM01, HMU, HMU, HM01, HMX, HMX, HM03, HMY, HMY, HM02, HMZ, HMZ, HM01, HN01, HN02, HN04, HN05, HN07, HNE, HNE, HN05, HNK, HNK, HN05, HNN, HNN, HN07, HNP, HNP, HN05, HNS, HNS, HN05, HNV, HNV, HN04, HNX, HNX, HN02, HNY, HNY, HN02, HNZ, HNZ, HN01, LDC, LEG, LEG, HNS, LES, LES, HNP, LES, HNZ, LEZ, LEZ, HMR, RH01, RHR, RHR, RH01, YH01, YHT, YHT, YH01, YHX, YHY, YHY, YH01, YHZ, ZM01, ZMZ, ZMZ, ZM01.

Codes OEM :

0109 2B , 0109-2C , 0109-2D , 0197-N , J-0109-2C , J-0109-2D , EN-52127-1 , EN-52127-2 , EN-52588.

Réf.
71548

